





CHANNEL/ROUTED LETTER INSTALL & REMOVAL

Step 1: Identify which connectors you will be attaching the letter to. (recommended to start from left side of the word/logo)

FRONT




BACK




Step 2: Line up all connectors before applying pressure to any connectors.

Step 3: Carefully apply pressure to each connector until you hear it click into place.


ISOMETRIC VIEW



SIDE VIEW



IMPORTANT!




To avoid damaging connectors, DO NOT install or remove at an angle.

ALL VIEWS HERE ARE SHOWN WITHOUT GRAPHICS FOR CLARITY. MOST CHANNEL LETTER INSTALLATIONS HAVE MOUNTING BOARD BEHIND GRAPHIC

Wiring is completed beforehand. Connection of jumper cables between power supplies may be needed.

— Wiring example —
Only one wire needed per lit element.



NOTE: Components used are job dependant, all componenets may/may not be used.

